

Dispensing & Punching System

The versatile RP series machine is easily tooled with secondary operation heads such as this pneumatic tool that pierces a slit into an elastomer valve after the dispensing operation.

The rigid machine tool quality (pre-loaded leadscrews and ball slides) construction provides excellent strength for punching and even press fit assemblies.

Custom fixturing allows fast changeovers and streamlines production loading and unloading in batches.



Software Controlled

The centerline offsets between the dispenser tip and the punching tool are simply added in the setup file to make programming a snap.

The dispense pattern may be imported from a CAD file, entered with commands, or taught with the machine using our advanced jog & teach path builder.

