



RD 6030 XYZ Fluid Dispensing Robot

Simply the best modular dispensing table available. It combines a smart work bench to a built in precision overhead servo XYZ gantry system.

Mechanisms are neatly tucked in and do not add to the width of the base. This provides easy access from front, sides and top requiring less operator "reach" to the center of the table.

Shown Tooled With:

Eight positive displacement servo heads on adjustable centers, for 2 part epoxy.

Many Smart Design Features

The full size vacuum platform features a hard coated (70 Rc) aluminum surface with thousands of holes for both vacuum hold down, and guide pin registration.

Under this table surface, the robust machine base is fabricated from heavy steel tubing, then the entire top is precision ground to a specified flatness.

Other types of top surfaces include:

- T Slot Table
- Vacuum Table
- Panel Conveyor
- Custom Plates

Standard machine can travel at over 25 inches per second and is available in the following travels:

■ 100" x 50" (2500mm x 1250mm)	RD-2500
■ 50" x 100" (1250mm x 2500mm)	RD-1250
■ 60" x 30" (1500mm x 760mm)	RD-6030

Be sure to inquire about our limitless customizing capabilities for other sizes and special tooling.

Great for: RTV, 2 part epoxy, hot melt, spraying, etc.

