

RD 2500 Large Format Fluid Dispenser



Simply the best modular dispensing table available. It combines a smart work bench to a built in precision overhead servo XYZ gantry system.

This dual headed system dispensed a hot melt and an RTV from bulk tanks to a precision volume onto door and window panels.

Many Smart Design Features

The T Slot table base featuring 25 Full length slots provides more than ample fixturing possibilities for most applications.

Under this table surface, the robust machine base is fabricated from heavy steel tubing, then the entire top is precision ground to a specified flatness.

This unique design provides the ideal foundation for mounting virtually any type of top surface including:

- T Slot Table
- Vacuum Table
- Hot Plates
- Panel Conveyor
- Custom Plates

Standard machine can travel at over 25 inches per second and is available in the following travels:

100" x 50" (2500mm x 1250mm)	RD-2500
50" x 50" (1250mm x 1250mm)	RD-1250

Be sure to inquire about our limitless customizing capabilities for other sizes and special tooling.

Shown with a combination of guarding including four light curtains, and removable mesh panels.



Great for: RTV, 2 part epoxy, hot melt, spraying, etc.

