

Robotic Dispenser Application 7



RP 1215 X with Granite Base & Vision
Auger valve with carbide components.
Capable of 0.0075" (190 micron) dots.



Axis 300 with Auger Valve & Tooling
Dispensing grease into plastic cavities.
Custom vacuum hold down fixturing.



Axis 300 with 1 Gallon Pressure Pot
General purpose dispenser with
diaphragm valve and pressure pot,
software controlled.



MG 2412 with 6 Heads and Conveyor
Includes independent control of 6
dispense valves and pallets on roller
conveyor system.



**RP 1215 with Positive
Displacement Syringe**
True positive displacement glass
syringe system driven by the robot.
Pre programmed



Axis 500 with 1/10 Gallon Canister
22" x 22" Travel. Includes high
pressure spool valve and caulk
tube pressure canister.



Axis 300 with Exclusive Rotating Tip
Programmable tip allows "reaching" into
grooves, inside diameters, etc.



RP 1215 RTV Valve, and Pick & Place
With 5 gallon pail pump, laser sensor
and scale for shot size verification.



Ring Dex 14 with Rotating Nests
Adhesive application inside lamp
housings. Removable nests for
quick changeover.